

Thank you for choosing our product! Please read through this user manual before using the product and keep the manual for future reference.



Shenzhen Rockrose Technology Co., Ltd.
Add.: Room 13A01, 14th Floor, Tower C, Shen Ye U Center,
734 Zhou Shi Road, Bao'an District, Shenzhen, P.R.C.
www.rockrosetech.com | info@rockrosetech.com
Designed by Rockrose L.A. Made in China

PRECAUTIONS


Do not dismantle, open or shred secondary cells or batteries.
Do not expose cells or batteries to heat or fire.
Avoid storage in direct sunlight.
In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical assistance immediately.
Secondary cells and batteries need to be charged before use.
Always store your power bank with at least a 50% charge in a cool and dry place to prolong the battery life. Storing while completely drained will reduce the capacity of the battery.

ROCKROSE



OASIS 10S POWER BANK
USER MANUAL

PRODUCT OVERVIEW



- 1 Power level button
- 2 Power indicator lights
- 3 Micro USB input port (2A)
- 4 Type-C input port (2A)
- 5 USB output port 1 (2.1A)
- 6 USB output port 2 (2.1A)
- 7 Lanyard hole

INSTRUCTIONS

Recharge Oasis 10S

Charge your Oasis 10S power bank with a power adapter that supports DC 5V/2A output for a rapid charge. A blinking power indicator light indicates the power bank is recharging.

Charge Devices Using Oasis 10S

Connect your Oasis 10S with a device using a suitable charger cable. The power indicator will show the current remaining power level during charging. This power bank can charge two devices simultaneously.

* Oasis 10S comes with a 30cm charge-only cable with Micro USB connector.

SPECIFICATIONS

Model Name: Oasis 10S
Model No.: RRPB02
Capacity: 10000mAh
Rated Energy: 37Wh (3.7V)
Battery: Li-Polymer
Input: 5V—2A (Micro/Type-C)
Output 1/2: 5V—2.1A (Max)

12 MONTHS WARRANTY PERIOD

Q.C. PASSED

CE RoHS

