

Thank you for choosing our product! Please read through this user manual before using the product and keep the manual for future reference.



Shenzhen Rockrose Technology Co., Ltd.
Add.: Room 13A01, 14th Floor, Tower C, Shen Ye U Center,
734 Zhou Shi Road, Bao'an District, Shenzhen, P.R.C.
www.rockrosetech.com | info@rockrosetech.com
Designed by Rockrose L.A. Made in China

PRECAUTIONS

Do not dismantle, open or shred secondary cells or batteries.

Do not expose cells or batteries to heat or fire.

Avoid storage in direct sunlight.

In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical assistance immediately.

Secondary cells and batteries need to be charged before use.

Always store your power bank with at least a 50% charge in a cool and dry place to prolong the battery life. Storing while completely drained will reduce the capacity of the battery.

ROCKROSE



ANDES 10S POWER BANK
USER MANUAL

PRODUCT OVERVIEW



WHAT'S IN THE BOX

- User manual x1
- Andes 10S x1
- 30cm charge-only cable with Micro USB connector x1
- Leather travel pouch x1

INSTRUCTIONS

Recharge the power bank

Recharge your Andes 10S power bank with a power adapter that supports DC 5V/2A output for a rapid charge. The blinking battery level indicator light indicates the power bank is recharging.

Charge devices

Connect the power bank with a device using a suitable cable. The battery level indicator will show the remaining battery level during charging. This power bank can charge two devices simultaneously.

SPECIFICATIONS

Model Name: Andes 10S
Model No.: RRPB07GR/RRPB07R
Capacity: 10000mAh
Rated Energy: 37Wh (3.7V)
Battery: Li-Polymer
Input: 5V~2A
Output1/2: 5V~2.1A (Max)

12 MONTHS
WARRANTY
PERIOD

Q.C.

PASSED

CE

RoHS

Recycling symbol

Warranty symbol