

Thank you for choosing our product! Please read through this user manual before using the product and keep the manual for future reference.



Shenzhen Rockrose Technology Co., Ltd.
Add.: Room 13A01, 14th Floor, Tower C, Shen Ye U Center,
734 Zhou Shi Road, Bao'an District, Shenzhen, P.R.C.
www.rockrosetech.com | info@rockrosetech.com
Designed by Rockrose L.A. Made in China

PRECAUTIONS

Do not dismantle, open or shred secondary cells or batteries.
Do not expose cells or batteries to heat or fire.
Avoid storage in direct sunlight.
In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical assistance immediately.
Secondary cells and batteries need to be charged before use.
Always store your power bank with at least a 50% charge in a cool and dry place to prolong the battery life. Storing while completely drained will reduce the capacity of the battery.

ROCKROSE



VOGUE 10 POWER BANK
USER MANUAL

PRODUCT OVERVIEW

Congratulations on your purchase of the Vogue 10 power bank. The Vogue 10 is durable, powerful and compatible.

Capacity

Rated at 37Wh/10000mAh, it can provide multiple charges to your phone, tablet, Kindle or other essential devices and gadgets

Dual Input Port

The Vogue 10 comes with two input ports (Micro-B and USB-C), both supporting 2A fast charge.

Battery Check

With Vogue 10, checking battery level is both intuitive and easy. With the push of a button, the LED on the button is lit white, and the length of the light bar corresponds to the remaining battery level, and it recedes as the battery level drops.

* Vogue 10 comes with a 30cm charge-only cable with Micro USB connector.

INSTRUCTIONS

Recharge Vogue 10

Recharge your Vogue 10 with a power adapter that supports DC 5V/2A output. Both the Micro USB port and the USB Type -C port can be used for recharging the power bank. The indicator light indicates the power bank is being recharged.

Charge Devices Using Vogue 10

Connect your Vogue 10 with a device using a suitable charge cable. The power indicator will show the current remaining battery level during charging. The length of the light bar on the button corresponds to the remaining battery level. This power bank can charge two devices simultaneously.

SPECIFICATIONS

Model Name: Vogue 10
Model No.: RRPB08W/RRPB08B
Capacity: 10000mAh
Rated Energy: 37Wh (3.7V)
Battery: Li-Polymer
Input: 5V~2A (Micro/Type-C)
Output 1/2: 5V~2.1A (Max)

