

**Thank you for choosing our product! Please read through this user manual before using the product and keep the manual for future reference.**



Shenzhen Rockrose Technology Co., Ltd.  
Add.: Room 13A01, 14th Floor, Tower C, Shen Ye U Center,  
734 Zhou Shi Road, Bao'an District, Shenzhen, P.R.C.  
www.rockrosetech.com | info@rockrosetech.com  
Designed by Rockrose L.A. Made in China

#### PRECAUTIONS

Do not dismantle, open or shred secondary cells or batteries.  
Do not expose cells or batteries to heat or fire.  
Avoid storage in direct sunlight.  
In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical assistance immediately.  
Secondary cells and batteries need to be charged before use.  
Always store your power bank with at least a 50% charge in a cool and dry place to prolong the battery life. Storing while completely drained will reduce the capacity of the battery.

**ROCKROSE**

**VOGUE 20 Pro** POWER BANK  
**USER MANUAL**

#### PRODUCT OVERVIEW

Congratulations on your purchase of the Vogue 20 Pro power bank! The Vogue 20 Pro is durable, powerful and compatible.

**Capacity**  
Rated at 74Wh/20000mAh, it can provide multiple charges to your phone, tablet, Kindle or other essential devices and gadgets.

**Dual Input Port**  
The Vogue 20 Pro comes with two input ports (Micro-B and USB-C), giving you more choices and much faster speeds to recharge. As the USB-C port supports PD, it can be used to either charge or discharge the power bank.

**Battery Check**  
With Vogue 20 Pro, checking battery level is both intuitive and easy. With the push of a button, the LED on the button is lit green, and the length of the light bar corresponds to the remaining battery level, and it recedes as the battery level drops.

#### INSTRUCTIONS

**Recharge Vogue 20 Pro**  
Charge your Vogue 20 Pro with a power adapter that supports USB PD output or DC 5V/2A or 9V/2A fast charge for an optimal rapid charge. A blinking power indicator light indicates the power bank is recharging.

**Charge Devices Using Vogue 20 Pro**  
Connect your Vogue 20 Pro with a device using a suitable charger cable. The power indicator will show the current remaining battery level during charging. As the Type-C port can be used for both input and output, this power bank can simultaneously charge up to three devices.

\* Vogue 20 Pro comes with a 30cm charge-only cable with Micro USB connector.

#### SPECIFICATIONS

Model Name: Vogue 20 Pro  
Model No.: RRPB14W/RRPB14B  
Capacity: 20000mAh  
Rated Energy: 74Wh (3.7V)  
Battery: Li-Polymer  
Input 1: 5V=2A 9V=2A  
Input 2: 5V=2A 9V=2A 12V=1.5A (Type-C)  
Output 1/2: 5V=3A 9V=2A 12V=1.5A  
Output 3: 5V=3A 9V=2A 12V=1.5A (Type-C)  
Dual or triple port combined output: 5V=3A

**12** MONTHS WARRANTY PERIOD

Q.C. PASSED

CE RoHS

